



RESIDENTIAL CARE INSTRUCTIONS

RT Baldwin Oiled Floor

Instructions for taking care of your Oiled Floor:

Below is a guide for maintenance of your oiled floor to help keep it looking beautiful forever. To ensure that you are able to enjoy your floors as they are meant to be, please take the time to read the following care guidelines and always use the recommended cleaner or its equivalent natural soap on your floor.

Prevention:

The maintenance of your floor starts at your entrance. Good floor mats will keep a large amount of dirt and debris off from your wood floors.



General Tips

- Put protective felt under all furniture legs, stationary and movable.
- Clean up spills as quickly as possible.
- Never place plants directly on your floors, always use a waterproof tray.
- Never use all purpose cleaners or steam mops on your hardwood floors.
- A room temperature ranging from 60–80 degrees Fahrenheit and a relative humidity level ranging from 30%–50% should be maintained year round.



Daily Care SUGGESTED MAINTENANCE

- Vacuum, sweep or dust mop regularly to remove loose dirt and debris.
- Frequent sweeping will cut down the amount of ground in dirt and reduce the number of needed deep cleans.
- Damp mop as needed.
- Never soak your floor or leave standing water.



Weekly/Bi-Weekly Care SUGGESTED MAINTENANCE

Specified

- Wash your floor with Specified Cleaner (or equivalent natural soap approved by the floor manufacturer).
- Dilute the product as specified on the bottle. Dampen the mop or spray lightly on the floor and wipe/work in with a soft microfiber cloth.
- Do not soak the floor or leave standing water.
- Do not scrub with an abrasive brush or pad.
- High traffic areas may require more frequent washing.
- For scuffs and/or unusually soiled areas, spot treat with a higher concentration of soap and water on a soft cloth.



Yearly Care SUGGESTED MAINTENANCE

- Inspect the floor every 6-12 months for signs of wear. Contact RT Baldwin with any questions or concerns.
- Dull marks and wear at high traffic areas are normal.
- Refreshing the oil finish may be needed every so often. Contact RT Baldwin for re-oiling of your wood floors.